

Happy Link / Happy Link LAN System

Supplementary Manual

How to transfer design data stored on network computer



SE100701-1

HAPPY Industrial Corporation

Contents

About this manual-----2

How to transfer design data stored on network computer----2

Setting example for Windows 7-----3

- 1. Setting of File Sharing----- 3
- 2. Setting of Network Drive ----- 6
- 3. Transfer design data from network drive ----- 9

About this manual

This manual is a supplement to Happy-Link and Happy-LinkLAN software manual.

Please use this manual together with Happy-Link and Happy-LinkLAN software manual.

This manual describes how to transfer design data stored on network computer to embroidery machine by Happy-Link and Happy-LAN software.

This function applies in Happy-Link A3.09 Happy-LAN A1.09 and in later version.

How to transfer design data stored on network computer

In order to transfer design data stored on network computer to embroidery machine, the following computer settings are required;

- A) Register the folder which stores design data as "Shared Folder" on Design Host PC.
In order other computer (which transfers design data to embroidery machine) to access to the folder on network computer, the folder which stores design data should be registered as "Shared Folder".
- B) Allocate "Shared Folder" to "Network Drive" on Machine Connection PC.
In order to access "Shared Folder" from a computer which is used for transfer design data to embroidery machine, "Shared Folder" should be allocated as "Network Drive" on a computer which has Happy-Link and Happy-LinkLAN software.
- C) Select design data from "Network Drive" which is allocated by step B) and transfer to embroidery machine with usual process of Happy-Link and Happy LAN.





Image of connection

Setting example for Windows 7



* Configuration details are varied by Windows type, please follow each Windows manual.

1. Setting of File Sharing



- 1-1) Select "Computer" from Windows Start menu.
- 1-2) Move the cursor to the folder to be registered as "Shored Folder", and right click..
- 1-3) Select "Share with".
- 1-4) Then select "Specific people...".



1-5) Choose "Everyone" and click Add button.




- 1-6) Set Permission Level of "Everyone" to "Read/Write".
1-7) Then click Share button.




2. Setting of Network Drive



- 2-1) Move the cursor to "Computer" from Windows Start menu and right click. Then select "Map network drive...".




- 2-2) Select drive (alphabet).



- 2-3) Click "Browse..." button and select folder which stores design data.
Then click OK button.



2-4) Then click Finish button for completing Network Drive Setting.




3. Transfer design data from network drive


On screen of design selection of Happy-Link or Happy-LAN, select network drive. Then select design data and transfer design data to embroidery machine as usual operation.

Please refer to manual of Happy-link and Happy-LAN for transfer design data to embroidery machine.

The followings are screens for network drive selection of Happy-link and Happy-LAN.



Design data selection screen of Happy-Link



Design data selection screen of Happy-LAN



HEAD OFFICE	9-16, 5-chome, Miyamachi, Yamagata-City 990-0057, Japan Phone: 023-623-7111 FAX: 023-623-2654
TOKYO OFFICE	2-9-5, Taito, Taito-Ku, Tokyo 110-0016, Japan Phone: 03-3834-0711 Telex: 265-5482 FAX: 03-3835-8917 Cable: HAPPYSEW TOKYO
HAPPY INDUSTRIAL GmbH	Am Kuemmerling, 10-12 55294 Bodenheim, (Mainz) Germany Phone: 06135-8101 FAX. 06135-3995